

S10X USER MANUAL



Warn: Automatic power off after 10 minutes without connection!

FUNCTION	DESCRIPTION	STATUS	BUTTON/METHOD	LED	VOICE REMINDER
POWER ON/OFF	power on	power off	press&hold 3s	flash in blue	power on+battery remind
	power off	power on	press&hold 3s	flash in red 1s	power off
POWER	battery detect	stand by	Intercom + press at the same time		remind the battery status
CN/EN Switch	Language Switch	stand by	Press twice	flash in blue	CN Mode/EN Mode
CELLPHONE CONNECTION	Bluetooth	power on	Triple-tap	flash in blue	connected
PHONE CALL	answer the call	incoming call	briefly press	flash in blue	tones same with cellphone
	reject	incoming call	Press&hold 2s	flash in blue	
	hang up	during phone call	briefly press	flash in blue	
	redial	stand by	Press twice quickly	flash in blue	
	voice command	stand by	press&hold 2s	flash in blue	
	Auto answering	Unconnected	briefly press	flash in blue	Enable automatic phone pick up/turn off automatic answering
MUSIC	play/pause	stand by	briefly press	flash in blue	play/pause
	volume +	stand by/play	Turn briefly counterclockwise	flash in blue	beep
	volume -	stand by/play	Turn briefly clockwise	flash in blue	beep
	previous	play	Turn long counterclockwise	flash in blue	
	next	play	Turn long clockwise	flash in blue	

FUNCTION	DESCRIPTION	STATUS	BUTTON/METHOD	LED	VOICE REMINDER
INTERCOM CONNECTION	pairing mode	power on	Triple-tap	flash between red&blue	paring
	searching mode	power on	briefly press Intercom button	flash in blue	searching
	cancel pairing	pairing	briefly press Intercom button		beep
	memory clean	connected	Intercom + press& hold 6s	flash in red	beep
INTERCOM	intercom on	connected	briefly press Intercom button	keep in blue	intercom on
	intercom off	connected	briefly press Intercom button	flash in blue	beep
	re-connect	power on	briefly press Intercom button		beep
EQ Sound	Sounds effect selection	Music	Press twice	/	Pure voice
		Music	Press twice	/	DJ
		Music	Press twice	/	Popular
Music Sharing	music sharing on	connected	Intercom + briefly press	flash between red&blue	music sharing on
	music sharing off	connected	Intercom + briefly press	flash in blue	music sharing off
FM	FM on	power on	+ briefly press	flash in blue	radio on
	FM off	FM on	+ briefly press	flash in blue	radio off

Configuration List



S10X INSTALLATION

